CONVENTIONAL FIRE ALARM OPERATING INSTUCTIONS

MF9300 SERIES

Access Code:- **2214**

User Features:-		**Access Code 2214**
1.	Silence	= Access Code + ENTER + SILENCE to mute
2.	Reset	= Access Code + ENTER + RESET
3.	**To Disable a Zone Example Zone 1**	**= Access Code + ENTER + → → → → → + DISABLE + ENTER**
4.	**To Re-Enable a Zone Example Zone 1**	**= Access Code + ENTER + → → → → → + ENABLE + ENTER**
5.	To Disable Remote Signal	= Access Code + ENTER + REMOTE SIG.ISO + ENTER
6.	To Re-Enable Remote Signal	= Access Code + ENTER + REMOTE SIG ISO + ENTER
7.	To Disable Alarm Lines (1&2)	= Access Code + ENTER → + DISABLE + ENTER
8.	To Re-Enable Alarm Lines (1&2)	= Access Code + ENTER → + ENABLE + ENTER